

Lift systemes

AMF-BRUNS CASSETTE LIFT K70

Premium Partner of Volkswagen Commercial Vehicles

Volkswagen Multivan T7







AMF-BRUNS CASSETTE LIFT K70

The ultra-slim AMF-Bruns cassette lift for the side sliding door





The ultra-slim K70 cassette lift combined with the vehicle heightening offers the best possible ground clearance.

THESE FACTS MAKE ALL THE DIFFERENCE

- » Load capacity 300 kg, complies with EN 1756, II
- » Ultra-slim design (70 mm) guarantees ultimate ground clearance
- » Illuminated controls, waterproof and shockproof
- Automatic roll-off barrier (also operates on uneven roads and snow)
- smooth operation of the lifting platform
- » Large lifting platform with side access; also suitable for large electric wheel-
- » Fully closed stainless steel cassette offers safe protection of the lift system, even in extreme weather conditions
- » No changes to the car body necessary
- » Vehicle interior remains unchanged
- » Powerful, silent running function ensures » Vehicle heightened by approx. 55 mm without impairing driving comfort
- » Manual emergency operation with hand pump
- Vehicle raised by approx. 55 mm, without compromising ride comfort
- Volkswagen has issued letters of nonobjection (LONO) for the installation of the lift and the necessary raising of the vehicle
- » EMC tested according to EU regulations

TECHNICAL DATA

» Height 70 mm

» Load capacity 300 kg

» Platform size approx. 760 x 1,200 mm

» Unladen weight approx. 170 kg » Lifting time approx. 7 sec.

» Lowering time approx. 7 sec. » Deploying/ approx. 12 sec. stowing

» Control By push buttons

Power Lifting and lowering electro-hydraulic 12 V; deploying and stowing by rack and pinion

drive 12 V

Bluetooth remote control including » Optional

app operation (iOS and Android)

MAXIMUM SAFETY

- » Automatic roll-over flap prevents feet from beeing trapped when the platform is lifted
- » Fully automatic roll-over protection barrier
- » Two LED flashing lights that switch on automatically to warn in poor visibility conditions
- » Safety switches prevent incorrect operation while driving



AMF-Bruns GmbH & Co. KG | Hauptstraße 101 | D-26689 Apen Telefon +49 (0) 44 89 / 72 72 50 | Fax +49 (0) 44 89 / 62 45 hubmatik@amf-bruns.de

